

# Welcome to the New Standard in Smoking Filtration by Scientific Inhalations

McFinn's Triple-Filtered Water Pipe kit comes with an 18mm glass bubbler, two glass filter tubes (either Standard or Ultra), a mouth piece, a bowl, two pics, plus one container of Activated Virgin Coconut Carbon and one container of Organic Cotton.

## Instructions

1. Pour cold water into bubbler until you reach the "water line".
2. Fill one glass filter tube with Activated Virgin Coconut Carbon leaving approximately 1/4" of airspace between the bottom of the joint frost and the Activated Virgin Coconut Carbon.
3. Place glass filter tube with Activated Virgin Coconut Carbon into female joint at the top of the bubbler making sure it is securely connected.
4. Place the glass bowl into the female joint that is on the top of the glass filter tube with Activated Virgin Coconut Carbon making sure it is securely connected.
5. Take one Organic Cotton ball, break it into half if your water pipe came with Ultra glass filters, break it into thirds if your water pipe came with Standard glass filters. Unroll the Organic Cotton so as to loosen it to help get a good draw.
6. Take your pic and push the Organic Cotton into the second glass filter tube making sure that it is loose. (DO NOT PACK THE COTTON INTO THE TUBE.)
7. Place the glass filter tube with Organic Cotton into the female joint in the arm on the side of the bubbler making sure it is securely connected.
8. Place the mouth piece into the female joint on the top of the glass filter with Organic Cotton making sure it is securely connected.
9. Start off with very small inhalations and over time you will determine how much of a draw you can take.

Over time you will find what your personal needs are with regard to how often to change your carbon, cotton, and water but we suggest you change your Activated Virgin Coconut Carbon when you notice that the cresol/tar has covered the carbons (approximately 100 inhalations); and to change your Organic Cotton when you notice that the cotton is turning a brownish color.

We also suggest that you get into the habit of changing your water in the

water pipe at the same time that you replace your Organic Cotton as the filtration works so well that your water will continue to look clean even when there are impurities within.

As for washing your water pipe simply rinse it with rubbing alcohol and warm water or use a commercial cleaner found at your local smoke shop.

Most Importantly –

**Enjoy! Your Health is Your Wealth!**

